



Wiring for 24C / 48C Seismograph

I. Wiring for 24C Seismograph




For Refraction / Surface Wave Exploration

II. Wiring for 24C Seismograph with Overlay Switch




For Shallow Reflection Exploration

III. Wiring for 48C Seismograph only using 24C




For Refraction / Surface Wave Exploration

IV. Wiring for 48C Seismograph without Overlay Switch



For Refraction Exploration

V. Wiring for 48C Seismograph with Overlay Switch



For Shallow Reflection Exploration